

playmobil®

family fun



70610



WARNING: CHOKING HAZARD

Contains a small ball and small parts.
Not for children under 3 years.

"Ne concerne que les USA"

1

Wichtige Unterlagen, bitte sorgfältig aufbewahren!
Important: Please keep these instructions for future reference!
Documents importants, à conserver soigneusement!
¡Por favor, guarde estas instrucciones para el futuro!
Belangrijke documenten, bewaar deze zorgvuldig!

Abbildungen können vom Original abweichen.
Product may differ from image shown.
Les illustrations peuvent différer de l'original.
Las ilustraciones pueden diferir del original.
Afbeeldingen kunnen verschillen van het werkelijke artikel.

Serviceadressen finden Sie in allen
PLAYMOBIL-Prospekten

Addresses of Customer Service Departments are shown in
all PLAYMOBIL catalogues

L'adresse du service consommateurs est indiquée dans
tous les catalogues PLAYMOBIL


Troverete gli indirizzi dei centri di assistenza in tutti i
cataloghi PLAYMOBIL

In alle PLAYMOBIL catalogi vindt u het adres van onze
klantendienst.

Las Direcciones de los Departamentos de Servicio al
Consumidor se encuentran en todos los catálogos
PLAYMOBIL


Η διεύθυνση του Γραφείου Εξυπηρέτησης Καταναλωτών
PLAYMOBIL βρίσκεται σε όλους τους καταλόγους PLAYMOBIL.

pronounced: plāy-mō-bēēl








3



4




5



6








2.




oder
or
ou







9



10










30 11 4690



30 62 3887

30 00 8454

30 62 3897



- DE** **AT** **CH** **LU** **BE** Nur Trinkwasser verwenden. Nach dem Spielen austrocknen lassen.
- US** **GB** **CA** **MT** **IE** Use only tap water. Dry thoroughly after play.
- FR** **CA** **BE** **LU** **CH** N'utiliser que de l'eau potable. Faire sécher après chaque utilisation.
- ES** **MX** Utilizar solamente agua potable. Dejar secar antes de guardar.
- NL** **BE** Enkel drinkbaar water gebruiken. Na het spelen laten drogen.
- IT** **CH** Usare solo acqua potabile. Asciugare bene dopo ogni uso.
- PT** Utilizar somente água potável. Deixar secar antes de guardar.
- DK** Anvend kun drikkevand. Lad det tørre ud når du er færdig med at lege.
- NO** Kun drikkevann skal benyttes. Tørk opp etter at leken er ferdig.
- SE** **FI** Använd endast dricksvatten. Låt torka efter användandet.
- FI** Käytää ainoastaan juomavettä. Anna kuivua leikin jälkeen.
- HU** Kérjük kizárólag ivóvizet használnjon! Játék után ajánlott a termék kiszárltása!
- CZ** Používat jen pitnou vodu. Po hraní nechat vyschnout.
- EE** Kasutada üksnes joogivett! Mängimise järel kuivatada!
- LV** Izmantot tikai dzeramo ūdeni. Pēc spēlēšanās ļaut nožūt.
- LT** Naudokite tik geriamąjį vandenį. Pažaidus, išdžiovinkite.
- SI** V igračo vlivajte le pitno vodo. Po igri naj se igrača posuši.
- SK** Používať iba pitnú vodu. Po hre nechať vyschnúť.
- PL** Używać tylko wodę pitną. Po zabawie pozostaw do wyschnięcia.
- TR** **CY** Sadece içme suyu kullanınız. Oyundan sonra kurumaya bırakın.
- GR** **CY** Χρησιμοποιείτε μόνο νερό βρύσης. Μόλις τελειώσετε, αφήστε το παιχνίδι να στεγνώσει εντελώς.
- RO** Se folosește doar apă potabilă. După joacă se lasă să se usuce.
- BG** Използвайте само питейна вода. След игра оставете да изсъхне.
- HR** Koristiti samo pitku vodu. Poslije igranja pustiti da se osuši.
- RU** Используйте только питьевую воду. Дайте высохнуть после игры.
- CN** 仅使用饮用水。玩耍后要干燥。



- (DE) (AT) (CH) (LU) (BE) **ACHTUNG!** Nicht auf Augen oder Gesicht zielen.
- (US) (GB) (CA) (MT) (IE) **WARNING!** Do not aim at eyes or face.
- (FR) (CA) (BE) (LU) (CH) **ATTENTION!** Ne pas viser les yeux ou le visage
- (ES) (MX) **¡ADVERTENCIA!** No apuntar a los ojos ni a la cara.
- (NL) (BE) **WAARSCHUWING!** Niet op ogen of gezicht richten.
- (IT) (CH) **AVVERTENZA!** Non mirare agli occhi o al viso.
- (PT) **ATENÇÃO!** Não apontar para os olhos ou face.
- (DK) **ADVARSEL!** Sigt ikke mod øjne eller ansigt.
- (NO) **ADVARSEL!** Sikt ikke på ansikt eller øyne.
- (SE) (FI) **VARNING!** Sikta inte mot ögon eller ansikte.
- (FI) **VAROITUS!** Ei saa kohdistaa suoraan silmiin tai kasvoihin.
- (HU) **FIGYELMEZTETÉS.** Tilos szemre vagy arcra célozni.
- (CZ) **UPOZORNĚNÍ!** Nemířte na oči nebo na obličej!
- (EE) **HOIATUS!** Ära sihi silmadesse ega näkku.
- (LV) **BRĪDINĀJUMS!** Nevērst pret acīm vai seju.
- (LT) **ĮSPĖJIMAS!** Netaikyti į akis arba veidą.
- (SI) **OPOZORILO!** Ne merite v oči ali obraz.
- (SK) **UPOZORNENIE!** Nemieriť do očí alebo do tváre.
- (PL) **OSTRZEŻENIE!** Nie celować w oczy i twarz.
- (TR) (CY) **ΔΙΚΚΑΤ!** Göze veya yüze doğru tutmayınız.
- (GR) (CY) **Προειδοποίηση!** Μην μῦν γίνεται στόχευση στο μάτι ή στο πρόσωπο.
- (RO) **AVERTISMENT!** Nu se țintește în ochi sau în față.
- (BG) **Внимание!** Не насочвайте към очите и лицето.
- (HR) **UPOZORENJE!** Ne ciljati u oči ili lice.
- (RU) **Внимание!** Не цельтесь в глаза или лицо.
- (CN) **警告!** 请勿瞄准眼睛或脸.



30 09 1710



30 25 9280



30 08 9183



30 08 9233



30 21 9240



30 08 6432



30 62 3957




30 88 0670




30 89 0972

2x 30 80 5005



30 08 9163



30 08 9173



30 62 3947



30 08 9113



30 08 9283



30 08 9043



30 22 9543



30 64 3512



30 25 8952



30 62 3937



30 27 6980



30 20 9043



2x 30 08 7963



2x 30 08 7973



30 89 0962



30 23 5030



30 65 8822



30 08 9303



30 27 3920



30 09 5680



4x 30 25 9453



30 62 3927



30 80 6823



30 08 9203



30 62 3917



2x 30 02 4240



30 09 5340



30 22 2740



30 23 8470



30 25 2063



30 25 9272



30 21 4793



2x 30 28 1650



30 25 2810




30 08 9243



30 08 9253



30 08 9263



2x 30 09 6900



2x 30 03 6600

UK-Importer:
Playmobil UK Ltd.
Regency House
1 Miles Gray Road
Basildon
Essex
SS14 3RW
UK

UK
CA



70613



70612



70611



70112



70614



70610



70609